





CAUTION: Disconnect power before opening indicator.

ASSEMBLY

The Indicator housing has liquid-tight cable connectors for load cell, communication (I/O), and AC power, as shown.

To open the housing, remove two screws on either side, and gently fold the front panel away from the rear panel.

Pass the load cell cable through the liquid-tight connector and the large ferrite bead attached to a plastic clip. Remove the screws holding the switch cover plate. Connect the load cell cable and wires as indicated on the diagram below.




Adjust Jumpers to match the load cell:

For a 2 mv/v load cell: short W1.

For a 3 mv/v load cell: open W1.


For a 4-wire load cell with no sense wires: short both W2 and W3. For a 6-wire load cell with sense wires, open W2 and W3.

For a load cell with an extra ground shield wire, connect the shield wire to "GND" on J2.



Mount the Indicator on its Wall/Table Bracket

Mount to a vertical or horizontal solid surface.
(Hardware not supplied.) Adjust angle, then tighten knobs.




Safety precautions:

- Be sure local power supply matches input voltage printed on Indicator label.
- Be sure the power cord does not pose an obstacle or tripping hazard.
- Disconnect the product when cleaning.
- Do not operate this product in hazardous or unstable environments.
- Use only approved accessories and peripherals.
- Operate the product only under ambient conditions specified in the Instruction Manual.
- Service should be performed by authorized personnel only.

CKW-55 Indicator Quick Start Guide

CONTROLS



	Primary Function <i>Short Press</i>	Secondary Function <i>Long Press</i>	Navigation Function <i>Menu Mode</i>
 Yes	ON/ZERO Turns indicator on. If indicator is on, sets zero.	Off Turns indicator off.	Yes Enters current menu (shown on display) Accepts current setting
 No	PRINT Sends displayed value to the serial interface	Units Changes weighing unit	No Advances to next menu. Rejects displayed setting, advances to next setting.
 Back	G/N/T Displays gross, net, tare values	Menu Enters menu mode	Back Moves back through menus. Backs out of menu setting.
 Exit	TARE Performs tare operation. Saves pre-set tare after numeric entry.		Exit Exits present mode, returns to weighing mode.
	LIBRARY Initiates library sequence: view/entry/edit.	Save Saves library data, loads it to active weighing mode.	
	NEXT +/- Adds displayed weight to accumulation memory. Toggles data: +/-	Displays statistical information of accumulation memory.	
	TARGET Initiates target sequence. Saves and steps through target data.		



OPERATION

On: Press **ON**. Indicator runs a display test, shows a series of informational displays, and enters active weighing mode.

Off: Press and hold **Off** until **OFF** appears.

Press **ZERO** to zero the weight display. Scale must be stable. Indicator zeros automatically at Power On.


Basic Weighing: Place item to be weighed on platform. The illustration indicates a sample of 1.5 kg, Gross weight.

Manual Tare: If weighing an item in a container, place empty container on the scale. Before taring, container's weight is shown (example 0.5 kg). Press **TARE**. Display shows zero. (If container is removed, display shows container's weight as negative.) To clear the Tare value, empty the platform and press **TARE**. The display shows gross weight (zero if platform is empty).

Pre-set Tare: enter a value on the keypad (eg, 1.000 kg). Press **TARE**. Display shows Pre-set Tare as negative value, with PT indicator on. (If **TARE** is not pressed within five seconds, display returns to previous mode without saving a tare.)

To clear a Pre-set Tare value, clear platform, press **TARE**. Display returns to 0 kg, Gross weight.

Displaying Gross, Net, Tare: When a tare has been entered, press **G/N/T** successively to display Tare, Gross, and Net weights. After a few seconds indicator automatically reverts to displaying NET weight.



ADDITIONAL OPERATIONS *(See Instruction Manual for details.)*

Changing Units of Measure: Press and hold **Units** until desired unit appears. Only measuring units enabled in the Readout-Unit Menu are displayed.

Accumulation: collect data from multiple weighings, eg, number of samples, total sample weight, average sample weight, standard deviation of sample weight. To add a value to Accumulation memory, place item on the platform, then short press **NEXT +/-**. Repeat this step for each additional item.

Checkweighing: enable it in Mode Menu. To check weight against preset target, press **Target**. Enter value with numeric keypad. Press **Next +/-** for negative or positive. Press **Target** to accept entry.



CKW-55 Indicator Quick Start Guide


MENU NAVIGATION

Press and hold  until MENU appears on the display. **CAL** appears.

Use **Yes**, **No**, **Back**, and **Exit** to navigate in Menu Mode:

 Yes	Allows entry / Accepts displayed setting and advances to next menu item.
 No	Skips displayed menu / Rejects setting or item, advances to next available item.
 Back	Moves backwards through menus.
 Exit	Exits directly to active weighing mode.

MENU STRUCTURE *(For more details, see Instruction Manual.)*



P/N 80253140